


INFLATABLE LUMBAR CUSHION




Instructions

Place this cushion against your chair at the desired position. Secure the cushion using the enclosed belt.

To Inflate Cushion

1. Twist knob until deflated.
2. Squeeze the attached hand pump (no more than 35 pumps) to inflate the cushion to the desired support. Do not over inflate.



To deflate, twist knob as shown in fig. 1.