

Anti-Vibration Air Glove®

**New Mechanic's Style Protection from IMPACTO®
Utilizing Patented Air Glove® Technology**

Certified ANSI S2.73-2002 (R 2007) / ISO 10819:1996

- ✓ *Synthetic ultra suede leather provides excellent wear and flexibility*
- ✓ *Textured patches on the palm and finger tips ensure superior gripping*
- ✓ *Mesh back allows hand ventilation*
- ✓ *Adjustable wrist tab with hook/loop closure*
- ✓ *Durable Urethane Air Bladder protects the palm, fingers and thumb*
- ✓ *Individual chambers for long lasting wear and consistent protection*
- ✓ *Excellent dexterity, fit and comfort*



Protects the worker from vibration when using hand-held or hand guided power tools and machines such as sanders, grinders, disc cutters, hammer drills, chipping hammers, chainsaws, brush cutters, hedge trimmers and powered mowers



The IMPACTO® Air Glove® reduces vibration energy transmission to the palm and fingers. Non-permeable polymer bladder with multiple individual air chambers provide effectiveness that won't degenerate. Soft, flexible bladder designed to conform to the flex-lines of the palm and fingers helping to maintain tool control. The multiple Air Chambers construction of the Air Bladder ensures long lasting wear and it won't bottom out. The Air Bladder helps prevent job specific impact and vibration hazards in the workplace.

Glove	Hand Size	Circumference
Small	7	7" - 8" / 15-18 cm
Medium	8	8" - 9" / 18-23 cm
Large	9	9" - 10" / 23-28 cm
XLarge	10	10" - 11" / 28-33 cm
XXLarge	11	11" + / 33 cm +

Model #BG408

Sold per Pair. For sizing measure the circumference of the hand at the base of fingers. Hand or machine wash in cold water and soft detergent. During use, grip tools firmly but do not over grip. Squeezing too tightly reduces the effectiveness of the bladder.

In Conformance with Norms

EN 10819:1996
Mechanical Vibration and Shock - Hand-Arm Vibration
EN 388:2003 Protective gloves against mechanical risks
EN 420:2003 General requirements for gloves



1 2 2 1

Innovative Protection

ISO 9001:2000



www.impacto.ca

Toll free N. America (888) 232-0031
Free phone UK 0800 0280 243
Tel (613) 966-0062 • Fax (613) 966-0067
E-mail: impacto@impacto.ca
PO Box 524, Belleville, ON K8N 5B2

Distributed by,